



PRODUCTS CHEMICAL

#100 GERMICIDAL CLEANER

hospital grade
disinfectant/deodorizer
cleaner

HOSPITAL GRADE
DISINFECTANT

A germicidal detergent intended for hospitals, institutions, schools, nursing homes, sanitariums, factories, offices, or any building to maintain sanitary premises.

ALL PURPOSE
DISINFECTANT

Clean, disinfect and deodorize floors, walls, sickroom equipment, and for instrument storage. Disinfects against athletes' foot in locker rooms and swimming pool surfaces.

MULTI-USE

Citrus-scented. For walls, equipment hard inanimate environmental surfaces. May be used with automatic floor scrubbing equipment for disinfectant-clean floors.

GERMICIDAL
DETERGENT

An EPA registered disinfectant. Effective against AIDS (HIV-1), Pseudomonas aeruginosa, Salmonella cholerae-suis and Staphylococcus aureus. Also, an effective fungicide.

CONCENTRATED

Concentrated for economy. It mixes with water to make a clear solution. When used as directed it is non-corrosive and non-staining on painted surfaces plastic tile, glass and most metal surfaces.

MILDEW
CONTROL

Use on enamel, porcelain, tile, and plastics to control mildew. An ideal cleaner for walls, floors, and industrial work areas, garbage cans and trucks, industrial waste receptacle. Effective in cellars and basements.

Refer to product label and SDS for additional information
© 1997 Products Chemical Company — All rights reserved



DESCRIPTION

Sparkling clear and clean! That is the results obtained with this disinfectant/detergent. It is a broad spectrum bactericide effective against a wide variety of gram positive and gram negative microorganisms. An excellent medium duty cleaner safe for use on all washable surfaces. A neutral pH makes it perfect for damp mopping floor finishes without dulling them.

APPLICATION

For disinfecting, deodorizing and cleaning nonporous inanimate surfaces

DIRECTIONS FOR USE

DISINFECTION - To disinfect hard, inanimate surfaces apply solution so as to wet all surfaces thoroughly. Allow to remain wet for 10 minutes and then remove excess liquid. For heavily soiled areas, a pre-cleaning step is required. Prepare a fresh solution for each use. GENERAL DISINFECTION - Add 2 ounces of this product per gallon of water. HOSPITAL DISINFECTION -Add 3 ounces of this product per gallon of water. To disinfect toilet bowls, flush toilet, add 2 oz. of this product directly to the bowl water. Swab the bowl completely. Let stand for 10 minutes and flush. This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or other wise enter normally sterile areas of the body. This product may be used to preclean or decontaminate critical of semi-critical medical devices prior to sterilization or high level disinfection. MILDEWSTAT - To control mold and mildew clean surfaces then add 2 oz. of this product per gallon of water Apply, making sure to wet surfaces completely. Let air dry.

SPECIFICATIONS

Packaged:Drums, 5- Enviro-pakl, 4- 1 gallons
Appearance: Yellow liquid
Fragrance: Citrus
pH: 11.70 (concentrate)
Flash point: None. Non-flammable
Quat type: Quaternary ammonium chloride
Authorization: EPA registered. USDA authorized
for use in federally inspected meat and poultry plants

PRECAUTIONS

Keep out of reach of children. Harmful if swallowed. Can cause eye or skin irritation. Keep away from eyes and skin. Do not take internally. Do not reuse empty container. Rinse empty container with water and discard. This product is intended for industrial and commercial use and storage by trained service persons only. Manufacturer will not be responsible for any injury, loss, or damage, if product is used in any manner not in compliance with label directions or if precautions are not observed.

FIRST AID

EYES: Immediately flush with large amounts of water for at least 15 minutes; contact physician. IF SWALLOWED: Do not induce vomiting or give anything by mouth to an unconscious person. Immediately get medical attention. EXTERNAL: Flush with large amounts of water.